
PENTAX® 645





ペンタックス645カメラに、67用交換レンズを使用するためのアダプターです。自動紋りの67レンズは開放測光で、クリックストップ紋リのレンズは紋り込み測光で撮影することができます。

- ※400mm以上の超望遠レンズでは、絞りや撮影距離等の条件によって画面周辺の光量不足およびケラレ等が発生します。使用する場合は4ページの適合表、または実写テストで光量不足の程度を確認の上お使いください。
- %レンズシャッター内蔵のLS165mmF4とタクマー90mmF2.8レンズは使用できません。また、シフト75mmF4.5レンズは、シフトして使用することはできません。
- ※645用のリアコンバーターは絞り連動が不安定 になるので使用できません。
- ※67用の接写リングやリアコンバーターは絞り 連動が不安定になるので使用できません。
- ※接写撮影には、645用の接写リングをご利用く ださい。なお、一部使用制限がありますので、 5~6ページの説明をご覧ください。 [説明文中、67レンズ用アダプター645をアダプター645と略します。]

大きさ----91[最大径]×14[厚み]mm 重さ------84 g 付属品---マウントキャップ The Adapter 645 for 67 lens is designed to mount the 67 interchangeable lenses onto the PENTAX 645 body. With this adapter, the automatic-diaphragm 67 lens permits the open aperture metering, while the manual diaphragm (click stop diaphragm systems) 67 lens permits the stopped-down metering.

- When the 400mm or longer ultra-telephoto lenses are used with this adapter, the edges or corners of the picture may be vignetted or darkened depending on the f-stop to be set and/or the camera-to-subject distance. Refer to the table on page 4, or first test-shoot to see if the results are acceptable when using this adapter.
- The LS 165mm f/4 with a leaf shutter and Takumar 90mm f/2.8 lenses cannot be used with this adapter. The shift 75mm f/4.5 lens cannot be shifted if used with this adapter.
- The Rear Converters A645 also cannot be used with this adapter.
- The 67 Rear Converters and the close-up accessories such as the Auto Extension Tubes or Extension Tubes cannot be used with this adapter.
- For close-up photography, use the 645 close-up accessories such as the Auto Extension Tube-A 645 or Helicoid Extension Tube 645. However, using them with 67 lenses involves some operational limitation. Refer to the explanations on pages 5 and 6.

Size: 91 (max. dia.) x 14mm (D) Weight: 84g Accessory: Mount cap

(The Adapter 645 for 67 lens will be called just the Adapter 645 in the following pages.)

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE.

組み立て方 ASSEMBLY








内爪交換レンズ

- 645ボディーとアダプター645の赤点指標を合わせてはめ込み、右に回すと自動的にロックされます。軽く逆に回してみて完全にロックされているか確認してください。
 645用接写リング等を併用するときは、ボディーとアダプター645の間に入れます。
- 2. 写真のように取り付けたアダプター645に、使用する67レンズを取り付けます。[取り付け方は、アダプター645と同じ操作です。]
- **3.67**用交換レンスを取り外すときは、矢印のロックボタンを押しながら、レンスを左に回すと外れます。
- *アダプター645をボディーから外して置く場合は、ボディー取り付け側のレバーを保護するために、付属のマウントキャップを必ず取り付けてください。


Changing the Inner Bayonet Mounting Lens

- Align the red indexes on the 645 body and Adapter 645, push in the Adapter 645, then turn clockwise. It will be locked in place.
 Slightly turn it counterclockwise to make sure that it has locked in place. When the close-up accessories for 645 are combined, fit them between the 645 body and the Adapter 645.
- Attach the 67 lens to the Adapter 645 as shown in the photography. (It attaches in the same way as the Adapter 645.)
- To remove the 67 interchangeable lens, turn the lens counterclockwise while pressing the lock button indicated by the arrow.
- Whenever this adapter is removed from the camera body, attach the Mount Cap to the adapter to protect the lever on the body mount side from being damaged.










外爪交換レンズ

٩

- 1.67用外爪交換レンズ [400mm F4など] の後部締め付けリングを 1 回転ほどゆるめて、白点指標が上部に来るようにします。
- 2.645ボディーに取り付けたアダプター645を締め付けリングの白点指標に合わせてはめ込みます。
- 3.写真のようにカメラをしっかり持ちなから、 締め付けリングを右に回して固定します。 外すときは、締め付けリングを左に回して白 点指標を合わせると外せます。
- ※このリングで締め付けたとき、リングの切欠き部がアダプター645の外爪バヨネット部と一致してしまうと固定したことにはなりません。リングが外爪バヨネット部を充分に固定したことを確認してから使用してくたさい。

Changing the Outer Bayonet Mounting Lens

- To change the 67 outer bayonet mounting lens (400mm f/4, etc.), slightly loosen the breechlock ring around the lens mount until the white index faces upward.
- Align the white index on the Adapter 645 that has been attached to the 645 body with the white index on the fastener ring.
- 3) Turn the ring clockwise to secure it while holding the camera as shown in the photograph. To remove the ring, turn the ring counterclockwise until the white indexes on the ring and adapter align.
- The breech-lock ring cannot be secured in place if the cut-out portions of the ring are aligned with the bayonet part of the Adapter 645.
 Confirm that the ring has firmly secured the bayonet part, then proceed to use.



ピントの合わせ方と露出の測り方

内爪バヨネットレンズ[自動紋リレンズ]は、紋 リF値をセットしても、ピント合わせは紋り開 放の状態で行なうことができます。

露出は、希望の紋リF値にセットして、開放測 光・自動紋リが運動します。

* 67用交換レンズの自動紋リ解除レバーはAUTO [オート]で使用します。MAN.[マニュアル]で

は、誤測光になりますからご注意ください。 外爪パヨネットレンズ [クリックストッフ紋リレンズ] でピントを合わせるときは、レンズの 紋りを開放紋りにして合わせます。

露出は希望の紋リ**F値**にセットして、紋リ込み 測光で適正露出を求められます。

67用内爪バヨネットレンズで接写をするとき アダプター645にオート接写リング A 645を組み 合わせて使うときは、開放測光・自動紋りが連 動します。[5ページをご覧ください] アダプター645にヘリコイト接写リング645を組 み合わせて使うときは、紋り込み測光になりま す。[6ページをご覧ください]

67用交換レンズ適合の注意

- 各超望遠レンズの絞りは、下表の範囲を目安にご使用ください。[ペンタックス400mmF4 ED[IF] レンズの絞り開放付近では画面周辺部に光量不足が少し表われることがありますので、F5.6以上の小絞りでお使いください。]
- ●レフ1000mm F 8 は、ケラレの発生が大きいので使用できません。
- ●下表以外の67用レンズは、全ての紋りで使用 可能。[レンズシャッター内蔵のタクマー90mm F2.8とLS165mm F4 およびシフト75mm F4.5 は除く]

Focusing and Exposure

With the Adapter 645 inserted between the 645 body and any inner-bayonet 67 lens (fully automatic), focusing can be done at the widest lens opening. Set the desired f-stop, and the camera and lens are coupled to offer the open-aperture metering and automatic-diaphragm operation.

 Be sure to set the Depth-of-field Preview Lever on the 67 lens to AUTO. If set to MAN (manual), light will not be measured properly.

When using a click-stop, outer bayonet mounting lens for focusing, open the lens aperture fully. Stop down the lens for stop-down metering to obtain correct exposure according to the f-stop selected.

Close-up Photography with 67 inner bayonet lenses

The open aperture metering and automatic diaphragm of the lens are made possible if the Adapter 645 and the Auto Extension Tubes A645 are used in combination. (see page 5.) Stop-down metering is used if the Adapter 645 and Helicoid Extension Tube 645 are used in combination. (see page 6.)

Remarks on the table below

- See the table below for reference when setting the aperture of the ultra-telephoto lens. The Pentax 400mm f/4 ED (IF) lens may cause light to fall off at corners near its maximum aperture, so use f/5.6 or smaller aperture for it.
- The Reflex 1000mm f/8 cannot be used as it causes great vignetting.
- The 67 lenses not listed below allow the use of all apertures. (with the exception of the Takumar 90mm f/2.8 lens with a leaf shutter, LS 165mm f/4 lens, and 75mm f/4.5 shift lens)
- O indicates the usable f stop.
- △ indicates light falls off at corners.
- × indicates that corners are slightly vignetted.
- indicates there's no intermediate click-stop.
- In the case of \triangle and \times , first test-shoot to see if the results are acceptable.

〇印は使用OK

△印は画面周辺の光量不足

- ×印は画面周辺が少しケラレる
- ー印は中間絞りのクリック なし

[△、×印での使用は、実写 テストで確認の上お使いく ださい]

アダプター645の適合表 Compatibility of Adapter and 67 Lenses

67 lens	4	٠	5.6	•	8	•	11~45	
400mmF4 ※	×	×	Δ	0	0	0	0	
500mmF5.6			×	_	Δ	-	0	
600mmF4	×	×	Δ	0	0	0	0	
800mmF4	×	×	×	· ×	×	Δ	0	
800mmF6.7				×	_	0	0	

オート接写リングA645 Auto Extension Tube-A 645

67レンズ+67レンズ用アダプター645+オート接写リングA645+ボディー 67 lens + Adapter 645 for 67 Lens + Auto Extension Tube-A 645 + 645 body





67用交換レンズで接写撮影をするときは、67レンズ用アダプター645を使い、さらにオート接写リング A 645を組み合わせて使用します。

リング A 645を組み合わせて使用します。 55~300mmの67用交換レンズが開放測光、自動 絞りで撮影できます。なお、下表のようにレン ズの絞りによって、画面周辺の光量不足やケラ レ等が発生します。下表または実写テストで光 量不足の程度を確認の上ご使用ください。

※ペンタックス200mmF4は、画面周辺部にわず かですが光量不足やケラレが出ますので、実 写テストで確認の上お使いください。

※レンズシャッター内蔵のタクマー90mmF2.8と LS165mmF4およびシフト75mmF4.5は使用できません。 For close-up photography using the 67 interchangeable lenses, the Adapter 645 and the Auto Extension Tube-A 645 are used in combination. This combination allows the use of a 55-300mm 67 interchangeable lens with the open-aperture metering and automatic-diaphragm of the lens. The picture may be vignetted or the light fall off at corners depending on the f-stop used, as shown in the table below. See the table below for reference or first test-shoot to see if the results are acceptable.

- The Pentax 200mm f/4 lens causes the picture corners slightly to be vignetted, or the light to fall off. First, test-shoot to see if the results are acceptable.
- The Takumar 90mm f/2.8 with a leaf shutter, LS 165mm f/4 lens, and 75mm f/4.5 shift lens cannot be used with this Auto Extension Tube-A 645.

67用レンズ連合表 [オート接写リングA645・セット] Compatibility of 67 Lenses (Auto Extension Tube-A 645 Set)

○印は使用OK

- △印は画面周辺の光量不足
- ×印は画面周辺が少しケラ レる
- 一印は中間絞りのクリックなし
- Oindicates usable f-stop.
- △ indicates light falls off at corners.
- × indicates corners are slightly vignetted.
- indicates there's no intermediate click-stop.

•		•										
F 67 lens	2.4	2.8	3.5	4	4.5	5.6	•	8	•	11	•	16~22
90mmF2.8		×	-	Δ	Δ	0	0	0	0	0	0	0
105mmF2.4	×	_	_	Δ	Δ	0	0	0	0	0	0	0
150mmF2.8		×	_	×	×	Δ	Δ	0	0	0	0	0
165mmF2.8		×	-	×	×	×	×	Δ	Δ	Δ	0	0
200mmF4 ≇1				×	T-	×	×	Δ	Δ	Δ	0	0
300mmF4 ±2					-	×	×	Δ	Δ	0	0	0
135mmF4			_	×	-	×	Δ	Δ	0	0	0	0

- ※1タクマーレンズ
- ※ 2300mmF4は絞りF45まで使用可能
- 2 Can be used up to f/45.

67レンス+67レンズ用アダプター645+ヘリコイド接写リング645+ボディー 67 lens + Adapter 645 for 67 Lens + Helicoid Extension Tube 645 + 645 body





67用交換レンズで接写撮影をするときは、67レ ンズ用アダプター645を使い、さらにヘリコイド 接写リング645に組み合わせて使用します。

55~200mmの67用交換レンズが絞り込み測光で 撮影できます。なお、下表のようにレンズの紋 リによって、画面周辺の光量不足やケラレ等が 発生します。下表または実写テストで光量不足 の程度を確認の上ご使用ください。

- ※ペンタックス200mmF4は、画面周辺部にわず かですが光量不足やケラレが出ますので、実 写テストで確認の上お使いください。
- ※レンズシャッター内蔵のタクマー90mmF2.8と LS165mmF4およびシフト75mmF4.5は使用で きません。

For close-up photography using the 67 interchangeable lens, the Adapter 645 and the Helicoid Extension Tube 645 are used in combination. This combination allows the use of 55-200mm interchangeable lenses with the stopped-down aperture metering. The picture may be vignetted or the light fall off at corners depending on the f-stop used. Refer to the table for reference or first test-shoot to see if the results are acceptable.

- The Pentax 200mm f/4 lens causes the picture slightly to be vignetted or the light to fall off at corners. First, test-shoot to see if the results are acceptable.
- The Takumar 90mm f/2.8 lens with a leaf shutter, LS 165mm f/4 lens, and 75mm f/4.5 shift lens cannot be used with this Helicoid Extension Tube 645.

〇印は使用OK

△印は画面周辺の光量不足

- ×印は画面周辺が少しケラ
- 一印は中間絞りのクリック なし
- indicates usable f-stop.
- △ indicates light falls off at corners.
- × indicates corners are slightly vignetted.
- indicates there's no intermediate click-stop.

67用レンズ連合表[ヘリコイド接写リング645・最長]

Compatibility of 67 Lenses (Helicoid Extension Tube 645; when fully extended)

67 lens	2.4	2.8	3.5	4	4.5	5.6	•	8	•	11~22
90mmF2.8	\angle	Δ	-	Δ	0	0	0	0	0	0
105mmF2.4	×	-	Δ	Δ	0	0	0	0	0	0
150mmF2.8		×	-	×	Δ	Δ	0	С	0	0
165mmF2.8		×		×	×	×	Δ	Δ	0	0
200mmF4 :#				×	_	×	Δ	Δ	0	0
135mmF4				Δ	_	Δ	0	0	0	0

*タクマーレンズ # Takumar lens

●お問い合わせは次の多サ

10/ 90 Printed in Japan 1



旭光学商事株式会社 代周医末面町|丁田||春||春| (500)206(代)

〒900 山台市南京区中央2丁県2番10号 山田会館 〒951 新州市车等进亡品幣1153番地 日本店幣新州ビル ービスセンター 学211 場点市中区不を取り丁酸6番99 場点エクセレントVビル 学420 新聞市出発和24番29 住民政治ビル ピスセンター ピスセン

-ビス無口へ

TM1 859596 91791984 ピスセンタ・ ービスセンタ ピスセンター 750 福州市海安区中州中央第3条89 -704 李中部中沙祖宗传播了岗北昌岭

毎日間・祝日および土曜日は京都として休みよう。ただし、年末年勤を称さべンタックスフォーラム(新宿)は毛中県はペンタックスフォーラム・大阪は戸道・祝日を休みます。

011(241)8742(Pt) 922(261)5681(Pt) G25(224)8301(15) # 045(691)6/71(rt) @ 052(962)5331(rt 762(22 X0501(rt)

.6(271)7906(rt) # 0821/4834321CH @ (92(281)6888(rt)